YOGA MAT BAG
PATTERN AND GUIDANCE



HOW TO
PUT YOUR DESIGN INTO A FULLPRINT PATTERN



Open the pattern file which you downloaded from the product page (please only use the pattern according to the size that you want to order) on Adobe Photoshop. Illustration is using Adobe Photoshop ....

ILLUSTRATED

HOW TO
PUT YOUR DESIGN INTO A FULLPRINT PATTERN

HOW TO CREATE WOMAN SMALL SLING BAG WITH YOUR OWN DESIGN



Need your attention:
1. Please pay attention to pattern part possition.
2.Black line is fabric/pattern cutting line.
3. Red mark on every corner is a sewing/ folding line



Guidelines



To avoid your design is beeing cutted/ distructed, follow these steps.

1. Enlarge the area using **Zoom tool** [ ] at left side so you can see the red at the corner.

2. Connect the red mark and you may see the **Red Area** as an estimated **sewing area** and **Green Area** is the estimated **your design area**.



FILLING PATTERN

HOW TO
PUT YOUR DESIGN INTO A FULLPRINT PATTERN

Open the pattern file and your design file on Adobe Photoshop.

1. Go to **Window** menu on the menu bar, select **Arrange** then **Title All Vertically** (**Window > Arrange > Title All Vertically**)





FILLING PATTERN

2. From your Design file, go to **Select** menu on menu bar then choose All (**Select > All**)





FILLING PATTERN

3. Goto **Edit** than **Copy** (**Edit > Copy**)



FILLING PATTERN

4. On the pattern file window, use the **Magic Wand** Tool (at tool bar on the left side) then left-click inside the part you want to work with





FILLING PATTERN

5. Go to **Edit** from menu bar then select **Paste Special** and **Paste Into** (**Edit > Paste Special > Paste Into**). You may adjust the pasted image by drugging it.





FILLING PATTERN

6. Before continue another part you should click **background layer** at layer list.



If layer list did not show you can easily press **F7** button on your key-board or go to menu bar **Window > Layer**

7. You can repeat selecting part by using **Magic Wand** and after you can **Paste Special** the design until all part filled.



SAVING FILE

As the final step you can Save your design by clicking from the menu bar **File > Save As**



For the file type change it to **JPG** format.

NOTE:
Minimum **Quality 8 (High)**
Please NOT to change **Image Size.**
Always aware of **Cutting/Sewing Part.**